


b. Turn on high beams.

(1) With headlights on, pull turn signal control lever (1) toward you.



(2) Ensure that high beam indicator comes on.

c. Return to low beams.

(1) Pull turn signal control lever toward you.

(2) Ensure that high beam indicator goes out.

## 2-17. OPERATE TURN SIGNAL INDICATOR

### NOTE

●Turn signal indicator will not operate unless service lights/blackout toggle switch is set to "SERVICE LIGHTS ON."

●Turn signal indicator will automatically turn itself off once turn is completed.

s. To indicate a left-hand turn, push turn signal control lever down. Ensure that left turn indicator on dashboard is flashing.


b. To indicate a right-hand turn, push turn signal control lever up. Ensure that right turn indicator on dashboard is flashing.

## 2-18. OPERATE WINDSHIELD WIPER/WASHER

### NOTE

**Windshield wipers are electric and will not operate if ignition switch is off.**

- a. To turn wipers on, twist knob (1) on end of turn signal control lever (3) toward front of truck to "LO" (4) for normal wiper speed or "HI" (5) for a more rapid wiper speed.
- b. To turn off wipers, twist knob (1) toward rear of truck to "OFF" (6).
- c. If a light mist requires only one wipe by wipers, this can be done by twisting knob (1) toward the rear of the truck to "MIST" (7).
- d. To operate windshield washer, push thumb plate (2) toward front of truck. Windshield wipers will automatically come on.



## 2-19. OPERATE HORN

### NOTE

**Horn will not operate unless service lights/blackout toggle switch is set to "SERVICE LIGHTS ON."**

Depress centerpiece (1) of steering wheel to sound horn.